


Despiece
Exploded view

ACCESSB5



- 1 Conjunto camisa
Cylinder sleeve Assembly
CJT50100F
- 2 Conjunto eje soporte
Support shaft assembly
CJT50500F
- 3 Embolo pistón
Piston plunger
ACC00X192
- 4 Junta estanquiedad
Sealing gasket
AS100X002
- 5 Tapeta pistón con guía
Piston cap with guide
ACC00X057N
- 6 Tubo final carrera eje
End-of-stroke tube (shaft)
ACC00X229
- 7 Tornillo DIN912 M8X80
DIN912 Screw
STA408080
- 8 Tuerca H DIN985 MB
Lock nut DIN985 MB
STA41008
- 9 Conjunto fijación silla
Chair fixation assembly
CJT50600E
- 10 Silla
Chair
AS100X016 (naranja)
AS100X016B (Blanca)
- 11 Pie tope a pared
Wall stopper foot
ACC00X222
- 12 Conjunto rueda inferior
Lower wheel assembly
AS100X016
- 13 Cjt. barra accionamiento
Drive bar assembly
CJT50200E

- 14 Esfera mando
Control Sphere
ACC00X005
- 15 Conjunto grifo
Tap assembly
CJT50300E
- 16 Reducción macho inox.
Stainless steel male reducer
GE7245020
- 17 Conector macho válvula 1/2"
1/2" male valve connector
GA18200
- 18 Adaptador PP
PP adapter
TEC008012
- 19 Tubo salida agua
Water outlet tube
T071
- 20 Conjunto reposa brazos
Armrest assembly
CJT50800E

- 21 Tornillo DIN6921 (9)
DIN6921 Screw
STA481016
- 22 Pasador de seguridad
Safety pin
CJT50700E
- 23 Tornillo (2)
Screw
SCB50601E
- 24 Tuerca ciega (2)
Dome nut
STA42010

- 25 Pie de anclaje
Anchor leg
CJT5110SE (s)
CJT5110ME (m)
CJT5110LE (l)
CJT5110XLE (xl)
- 26 Anclaje de suelo
Surface anchoring base
CJT51000E
- 27 Tapón anclaje
Anchor cap
STA010004
- OPCIONAL**
- 28 Conjunto reposapiés
Footrest assembly
CJT51200E
- 29 Manómetro
Pressure gauge
CJT51500E